



ANNUAL OVERSIZE/OVERWEIGHT PERMIT APPLICATION

Phone: (319)352-4302
 Email: countyengineers@co.bremer.ia.us

Permit Fee \$400 Oversize/Overweight \$50.00 Oversize

Permit No: _____

Section A - Issued to: Please print clearly or type

| | | | |
|--|-------|--|--|
| <input type="checkbox"/> Check <input type="checkbox"/> Cash | | Requested Valid Dates | |
| Check # | | | |
| Legal Name- Vehicle Owner or Lessee | | Phone Number | U.S. DOT Number |
| Address | | FAX Number | MC Number |
| City | State | ZIP Code | Carrier Type <input type="checkbox"/> For Hire <input type="checkbox"/> Private |
| Email Address | | Iowa Intrastate Authority Number | |
| | | Contact Name for DOT to call if questions / Area Code- Telephone No. | |

Section B - Power Unit Information

Power Unit- Both Plate/State and VIN must be identified.

| | | | | | |
|-------|-------|-------------------------------------|-------------------|------|------|
| Plate | State | Vehicle Identification Number (VIN) | Registered Weight | Year | Make |
|-------|-------|-------------------------------------|-------------------|------|------|

Section C - Dimensions/Weight

| | Length (max= 120') | Width (max= 13'5") | Height (max = 15'5") | Total Weight (max=156,000lbs) | Front Projection (max= 15') | Rear Projection (max= 15') |
|-------|-----------------------|-----------------------|-------------------------|----------------------------------|--------------------------------|-------------------------------|
| Total | | | | | | |

MAXIMUM AXLE WEIGHTS ALLOWED ON THIS PERMIT = 20,000 LBS PER AXLE

Section D -Axle Weight/Spacing - front to rear (required for SME vehicles only)

| | | | | | | | | |
|-------------------------|-----------|---|---|---|---|---|---|---|
| Axle Number | 1 (front) | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| Gross Axle Weight (lbs) | | | | | | | | |
| Axle Spacing | | | | | | | | |

Section E- Permit delivery (check one)

| | |
|--|--------------------------------|
| Name | |
| <input type="checkbox"/> Mailing Address | |
| <input type="checkbox"/> FAX | <input type="checkbox"/> Email |

Acceptance of Conditions: I certify that the statements contained in the application are true and correct and I will comply with the General Provisions dated 01-2014.

 (Customer or Authorized Agent) Date

Authorized By:

 Bremer County Engineer's Office Date

Maximum dimensions and weight allowed on an annual oversize/overweight permit are: length - 120', width - 13'5", height - 15'5", weight - 156,000 lbs. Enter actual dimensions if self-propelled oversize/overweight vehicle.

Separate permits must be obtained from the proper governing authority for travel on roadways.

It is the responsibility of the carrier to route themselves around low clearances, construction projects, embargoed roads and bridges. If carrier demonstrates inability to self route, the permit will be revoked. Information is available at www.iowadot.gov/mvd/omcs and www.511.ia.org to obtain information for self routing.

Permits can be issued only for transporting single articles that exceed statutory size limits unless the inclusion of additional articles does not cause the size or weight to further exceed the statutory limits.

IOWA GENERAL PROVISIONS FOR OVERSIZE LOAD PERMIT

IOWADOT

Form 442052 (07-23)

The State of Iowa, the Iowa Department of Transportation, and any other permit issuing authority assume no responsibility for the property of the permit holder. During movement under permit, the permit holder must meet the terms and conditions of the permit and must take all reasonable precautions to protect and safeguard the lives and property of the traveling public and adjacent property owners. A copy of a current certificate of public liability insurance in the amounts of \$100,000 bodily injury each person, \$200,000 bodily injury each occurrence, and \$50,000 property damage must be carried in the vehicle for which the permit has been issued. Nothing shall exempt the permit holder from compliance with any load limitations that have been or might be established on any bridge or road posted with embargo signs. The permit and any revisions will be void if the actual weights or dimensions exceed what is indicated on the permit or its revisions. Permits can be issued only for loads that are a single article that cannot be reasonably broken down to make it legal in size and weight. The permit must be carried in the cab of the vehicle for which it has been issued and be available for inspection. Proof of liability insurance may be either in writing or in electronic format.

Movement is allowed seven days a week except for designated holidays and for special events when abnormally high traffic counts can be expected. The designated holidays are Memorial Day, Independence Day, and Labor Day. No movement will be allowed on these holidays or after 12 noon on days preceding these holidays and holiday weekends that include holidays falling on Monday, except as provided for in Iowa Code 321.457.

Annual permits: Routes must be checked for construction restrictions and clearance problems using the vertical clearance maps, bridge embargo maps, pavement restriction maps, and the 511ia.org website prior to moving under permit. Maps can be found at iowadot.gov/mvd/motorcarriers.

Escort requirements: Escorts must be at least 18 years old, possess a valid Class A, B, C, or D driver's license, and carry proof of public liability insurance in the amounts of \$100,000/\$200,000/\$50,000. The escort vehicle must be approximately the size of a normal passenger automobile or pickup and must have a flashing or strobe amber light that shall be burning while escorting a permit load. The escorting vehicle shall not be used to tow a trailer while performing escorting duties. The escort shall not assume responsibility for stopping traffic. An on-duty peace officer, as defined in Iowa Code section 321.1, shall be contacted to provide any traffic control needed.

Required warning devices and escort requirements for vehicles operating under permit

| | Flags/Signs | Lights | Escorts | |
|---------------------------------------|--------------|--------------|--------------------------|--------------------------|
| | | | Four-lane | Two-lane |
| Length | | | | |
| 75'1" up to and including 85' | Yes | No | Not required | Not required |
| Over 85' up to and including 120' | Yes | Yes | Not required | Not required |
| Over 120' | Yes | Not required | Rear | Rear |
| Projections | | | | |
| Front: over 25' | Not required | Yes | Not required | Not required |
| Rear: over 4' up to and including 10' | Flags only | Not required | Not required | Not required |
| Rear: over 10' | Flags only | Yes | Not required | Not required |
| Height | | | | |
| Over 14'6" up to 20' | Yes | Not required | Front with a height pole | Front with a height pole |
| Weight | | | | |
| Over 80,000 lbs. | Not required | No | Not required | Not required |
| Width | | | | |
| Over 8'6" up to 12' | Yes | Not required | Not required | Not required |
| Over 12' up to and including 14'6" | Yes | Not required | Rear* | Front* |
| Over 14'6" up to and including 16'6" | Yes | Not required | Rear* | Front |
| Over 16'6" up to and including 18' | Yes | Not required | Rear | Front |

*In lieu of an escort, a vehicle can display an amber light or strobe on the power unit and on the rear extremity of the load.

Lighting requirements: A flashing or strobe amber light that is visible for at least 500 feet and provides 360-degree warning, mounted on the towing unit is required. An escort can be used in lieu of amber light.

Signs and flags: A sign reading "Oversize Load" must be at least 18 inches high by 7 feet long with a minimum of 10-inch black letters with a 1 1/2-inch stroke, on a yellow background, and mounted on the front bumper and on the rear of the load. A rear sign for mobile homes must be mounted at least 7 feet above the highway surface, measuring from the bottom of the sign. Flags must be red or orange fluorescent and at least 18 inches square. Flags must be mounted as follows: one flag at each front corner of the towing unit and one flag at each rear corner of the load. In addition, there must be a flag at any additional protrusion in the width of the load. The signs or warning devices must be mounted so they can be removed or covered when the vehicle is within legal dimensions.

Permitted tandem axle weights: Vehicles operating under a permit issued pursuant to Iowa Code 321E.8, 321E.9, or 321E.9A may have a gross weight not to exceed 46,000 pounds on a single-tandem axle of the truck tractor and a gross weight not to exceed 46,000 pounds on a single-tandem axle of the trailer or semitrailer if each axle of each tandem group has at least four tires. No single axle of the tandem group may exceed 24,000 pounds. If the tandem axle is within a larger group of axles, the maximum weight of that specific group of axles shall not exceed 20,000 pounds per axle.

Requirements for continuous moves: Vehicles and loads may travel by permit between 112 hours after sunset and 112 hours before sunrise if, in addition to the general provisions and general requirements specified by the permit, the following conditions are met.

- a. Dimensions shall not exceed:
 - (1) Width: 11 feet.
 - (2) Height: 14 feet, 6 inches.
 - (3) Length: 100 feet.
 - (4) Weight: Permitted axle limits.
- b. Travel must be on roadways with a minimum width of 22 feet and minimum lane width of 11 feet.
- c. Safety lighting shall be provided at the widest part of a load. The lamps may be placed at the outer ends of the load itself or on appurtenances that are equal in width to the widest part of the load and positioned at both extreme front and rear of the vehicle or trailer as follows.
 - (1) One lighted red lamp on each side at the rear of the load.
 - (2) One lighted yellow or amber lamp on each side at the front of the load.

FOR MORE INFORMATION, CALL 515-237-3264



INSTRUCTIONS FOR COMPLETING AN ANNUAL OVERSIZE PERMIT APPLICATION

Section A – Issued To

Check or Cash: Check the box next to your desired method of payment.

Requested Start Date: Enter the date you would like the permit to start. Permits are good for one year.

Legal Name: Enter the name of the person or company that the permit will be issued to.

Phone Number: Enter the contact phone number.

MC Number: Enter your MC number if you are a for hire carrier with Interstate authority.

Intrastate Authority: Enter your Iowa Intrastate authority number

Carrier Type: Check one box. Are you hauling this load for hire or privately?

Address/City/State/ZIP: Enter the address of the person or company that the permit will be issued to.

Fax Number: Enter the contact fax number.

US DOT Number: Enter your USDOT number here. If no USDOT number is required for your operation, enter NA. To determine if you are required to have a USDOT number, visit the web site www.safersys.org

Email address: Enter your email contact information.

Contact Name: Enter the name of the person to be contacted with questions regarding this application. Also enter a phone number if different than the one already on the application

Section B - Power Unit information

Plate: Enter the license plate number for the power unit.

State: Enter the 2 digit abbreviation for the state the power unit is registered in.

Vehicle Identification Number (VIN): Enter the VIN for the power unit.

Registered Weight: Enter the registered weight of the power unit. This information can be found on your cab card. Iowa law requires that you be registered for the weight you are hauling. Please include a copy of your cab card with the application.

Year: Enter the year of the power unit.

Make: Enter the make of the power unit (Peterbilt, Mack, International, etc)

Section C – Dimensions/Weight

Overall Length: Measure from the front bumper of the power unit to the end of the trailer or load. Enter in feet and inches.

Overall Width: Enter in feet and inches.

Overall Height: Tallest point, either power unit or load. Enter in feet and inches.

Front Projection: Any overhang that extends past the front of the power unit. Enter in feet.

Rear Projection: Any overhang that extends past the rear of the power unit; or trailer if a combination vehicle. Enter in feet.

Overall Gross Weight: Total weight of power unit, trailer, and load combined. Enter in pounds.

Section D - Axle weights

If special mobile equipment with qualifying tires, enter individual axle weights and spacings. If not SME, skip to next section.

Requested Gross Axle Weight: Enter weight for each axle in pounds.

Section E - Permit delivery

Check the appropriate box telling us how you would like your permit delivered to you once it has been issued. Choose Mail, Fax, or email, and fill in the corresponding information.

Acceptance of conditions: Sign on the line to certify that you have read the "Iowa General Provisions for Oversize Load Permit" - your signature acknowledges that you have read and will comply with them.